

Reverse Drive Adapter Notes:

- 1. The machining of the adapter is dependent upon the dimensions of the friction disk, Part 23.2.5, that you use. Many sizes are available.
- 2. The face of this adapter is turned such that an edge (or step) radius is the same as the ID of the friction disk.
- 3. Take care welding to not warp parts.
- 4. To locate the 4 holes to drill and tap clamp adapter to friction disk and mark the holes location.